

Genecon and Static Genecon

How can we deal with the dirt from the felt for the static high voltage GENECON?

Since it is important that the felt keeps fluffing, dirty felt can be used as is.

Unique solution ID: #1029

Author: james

Last update: 2012-06-18 19:01