

# TRANSAXLE CUT-AWAY, CONTINUOUS VARIABLE TRANSMISSION (CVT)

N98-ND11068



The CVT Gearbox or Continuously Variable Transmission Gearbox can change continuously through an infinite number of effective gear ratios between maximum and minimum values. There are two V-belt pulleys that are split perpendicular to their axes of rotation, with a V-belt running between them.

This cut-away model has been carefully sectioned for training purposes and professionally painted with different colors to better differentiate the various parts. Many parts have been chromium plated and galvanized for a longer life.

## SPECIFICATIONS

- Electromagnetic clutch
- Forward and reverse insertion lever
- Primary pulley
- Secondary pulley
- Roller belt
- Final reduction unit
- Hydraulic command unit
- Mounted on stand with wheels
- Operated manually by hand crank

## WEIGHT & DIMENSIONS

60cm x 50cm x 80cm (L x W x H)

Net Weight: 45 kg

Gross Weight: 75 kg



MOUNTED ON STAND  
WITH WHEELS

Version2.1.JL030916



LOOK US UP ONLINE